

Wiring for Classic Video Intercoms

For the indoor monitor the 4 wires are:

- 1 = Blue = Audio
- 2 = Black = Ground (or negative)
- 3 = Red = positive (V+)
- 4 = Yellow = Video

For the outdoor camera the 4 wires are

- 1 = Red = Audio
- 2 = Blue = Ground (or negative)
- 3 = Yellow = positive (V+)
- 4 = White = Video

Connect 1:1, 2:2, 3:3, 4:4, using CN1 on the monitor for the 1st outdoor station and CN2 for the 2nd outdoor station.

Do NOT match the colours, match the numbers.

Each monitor requires its own power from the plug pack supplied.

It may be necessary to extend the lead on the plug pack with figure 8 cable.