


## JB-304 Video Villa Door Entry System User's manual (V1.0)


Hi, thanks for using our products. As there are so many designs, it is hard to show all here. Please kindly use the device you have received with this manual accordingly.

### 1. Answer a call


When you want to answer a call, please pick up the handset or push  button.



or



### 2. Release the door


When you want to release the door, please push  button during communication.



or







### 3. Surveil the entrance

When you want to surveil the entrance, please push  button.





or




**⚠️** ① If there are two or more door stations and before the screen shuts off, you can continue to push  button and surveil the different entrances by turn. ② During surveillance you can push  button to communicate with somebody outside, and then push  button to release the door.

### 4. Call other indoor phones


When you want to call other family members nearby the other indoor phones, please pick up the handset or push  button (hands-free), and then keep pushing  button for 2 seconds.





or



### 5. Call transfer

When you answer a call and want to transfer to another indoor phone, please push  button to ring. After somebody answers there, your indoor phone will shut off automatically.

### 6. Broadcast

When you need to speak to other family members nearby the other indoor phones, please pick up the handset and push  button or just push  button (handsfree) and then speak.






or



**⚠️** Function 4, 5 and 6 are available only for the houses where there are two or more indoor phones.

### 7. Change the ring tone

If you want to change the ring tone, please keep pushing  button for 2 seconds when the indoor phone is idle. Then push the button again and again until you get a favourite ring tone. You may wait until the ring stops itself, or push  button to confirm and stop the ring.



or






### 8. Adjust the image quality

If you want to change the image quality, please push  button and then  button firstly.



or



Move CONTRAST  & BRIGHTNESS  adjusters.

Push "MENU" button, the screen will show "CONTRAST", "BRIGHTNESS", and "COLOR" by turn, then push "+" and "-" buttons to adjust their scales.

### 9. Adjust the ring & speech volume

If you want to adjust the ring and/or speech volume, please turn the wheel as the following figure.



**⚠️** All handsets are not available to adjust the ring and speech volume.