

Packing List



Switch x.1


Power Adapter x.1

Quick Start Guide x.1


Interfaces

Front Panel

DS-3E0105XX Series:



DS-3E0109XX Series:



Applicable Models

This manual is applicable to DS-3E0105XX and DS-3E0109XX series 100M long-range PoE switch.

Symbol	Description
	Provides additional information to emphasize or supplement important points of the main text.
	Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
	Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.

NOTE
 - During the installation and utilization of the device, please strictly conform to electrical safety rules in different nations and regions.
 - Ensure to use the attached power adaptor only and not to change the adaptor randomly. Please refer to specification table for specific requirements of power adaptor.
 - Never attempt to disassemble the camera yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

WARNING
 - The device must be installed in machine room only, and only maintenance staff or qualified person should access to the device.
 - Do not touch the upper cover area of the device that may be overheated.
 - Power must be shut down during cable connection, device installation, and device configuration.
 - You shall acknowledge that the use of the device with internet access might be under network security risks, please strengthen protection for your personal information and data security. If you find the device might be under network security risks, please contact with us.
 - Configuration of all accounts and other security settings is the responsibility of the installer, and you shall keep user name and passwords properly.
 - Please keep all original packing materials properly. If the product does not work properly, pack the switch in its original packing materials for shipping. We shall not assume any responsibility for damages caused by improper packing materials during shipping.
 - The device is not certified for use in aircraft and other restricted areas. Please refer to the fire-proofed, because the switches are not compliant with the Limited Power Source (LPS) standard.

1

2


3

4

5

Device Connection


Connect your devices according to your actual networking requirements.



4-Port 10/100M PoE
 10/100M Unmanaged PoE Pro-Series

PoE Ports
 100M PoE ports connect to other PoE devices with network cable.
UPLINK
 100M network port connects to other switches with network cable.
PWR Indicator
 Solid means powered up normally. Unit means no power supply connected or power supply is abnormal.
PoE-MAX Indicator
 Solid/flashing means the output power of the switch will reach the upper limit, and the power supply may be abnormal if more devices are connected. Unit means power supplying is normal.

Rear Panel



DIP Switch

On: Extend model is on, connecting PoE port 1-4 (4 ports), 1-8 (8 ports).
 Off: Extend model is off.

Grounding Terminal

The grounding terminal connects with ground cable in case of lightning.

Power Port

Connect power port of the switch with power socket with power cord to provide power to the switch.

